

## 5.1 PARTS LIST— CONTROL BOX

Fig No.	Part No.	Description	Q'ty.	Remark
1	* 3224-1001	Magnetic Contactor	1	MC
2	3021-2001	Inverter 1phase	1	INV
	** 3021-4003	Inverter drives	1	INV
3	3311-0018	Transformer	1	T1
4	* 3323-0001	Power supply	1	PS
5	3214-4006	Push button (w/ light)	1	PB1
6	** 3222-2002	Circuit breaker	1	NFB 230VAC
	** 3222-3002	Circuit breaker	1	NFB 460VAC
7	3121-4003	Male connector plug 7Pin	1	JN2
	3122-4003	Female socket 7Pin	1	JN2
8	3534-3005	Cable clamp	1	P1
9	3122-7002	Female socket 17Pin	1	JN4
10	3023-0003	Remote control 7.5M	1	
11	* 6652-1211	PC Board	1	PCB
12	3211-4105	Select switch	1	SW1
13	3422-0006	Terminal	3	TB
14	3122-4004	Female socket 10 Pin	1	JN5

\* Recommended spare parts

\*\* Options

# 5.1 PARTS LIST—CONTROL BOX

