

Pilot Flame Function Torch

The 342T Series features Gas Saver On/Off Lever, which is designed for immediate On/Off control of the oxygen and fuel gases for precise gas control. The pilot adjustment allows for maintaining a small pilot flame for immediate acceleration of the flame on the brazing tip. 342T-Y is used with Acetylene/MAPP® and 342T-F is used with other fuel gases.



342T-Y Light Duty



342T-F Light Duty

Model Number	Welding Range	Weight / Length	Using Cutting Attachment	Uses Welding Nozzle	Uses Heating Nozzle
342T-Y	1/2"	0.7 lb. 6-5/8"	141C	171W, 871W, 881W, G17-VMA-1 GMTW, GMTT, GMTR, G17-FT, G13-8VM	171H
342T-F	1/2"	0.7 lb. 7-3/4"	141C	G17, 881W	171HN

Note: When using heating nozzles and cutting attachment, the Pilot Flame Function should not be used. Available with torch end check valves (add"-CV" to model number) or flashback arrestors (add"-FA" to model number)